## 3100SSST - CURVE NECK SELF TRIM JUMPER

Α	1/2 CHEST WIDTH - Measure around the chest area located 2.5cm below Armhole.
В	BODY LENGTH Measure from Hight Point Shoulder (HPS) to Hem edge.
С	1/2 WAIST - Measure around the natural waist line, online with the navel. 1/2 BODY SWEEP - Measure around the hem of the garment. For shirts with slits or around hem, measure above the slit or curve of the hem.
D	BACK NECK WIDTH  Measure at the natural shoulder line at the collar/rib join seam straight across to the opposite seam.
Е	1/2 ARMHOLE STRAIGHT Measure from the shoulder point straight down to the bottom armhole seam.
F	FRONT NECK DROP Measure down from center HPS to seam at center of the half moon



MEN'S LOSSE FIT 2 SLEEVELESS JUMPER (CM)								
SIZE	CHEST WIDTH	BODY LENGTH	WAIST / BODY SWEEP	BACK NECK WIDTH	ARMHOLE STRAIGHT	FRONT NECK DROP		
2	33	47	33	10	13	11		
4	37	53	37	10.5	14	12		
6	39	55	39	11	15	13		
8	40	57	40	11.5	16	15		
10	43	62	43	12	18	15		
12	46	66	46	12.5	19	15		
14	48	68	48	13	21	15		
S	51	72	51	13	20	15		
М	53	74	53	13.5	22	15		
L	55	77	55	13.5	23	15		
XL	57	79	57	13.5	24	15.5		
2XL	62	82	62	14	26	15.5		
3XL	66	84	66	14.5	28	18		
4XL	68	87	68	15	29	18		
5XL	70	89	70	15.5	30	18		